

INDASH by PANAVISE®

I-751101707

Page 1 of 1

MOUNTING LOCATION:

Right Side of Radio Cavity KR

TOOLS REQUIRED:

Dash Tool - Plastic (Wide)

Phillips screwdriver

HARDWARE INCLUDED:

(3)A - #8x9/16" Needle Pt. Screw

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 751101707

MFG: CHEVY / GMC

MODELS & YEARS:

CHEVY - Silverado LTZ&XLT 2007-13,
Tahoe 2007-13, Surburban 2007-13,
Avalanche 2007-13

GMC- Sierra SLT 2007-13, Yukon 07-13

(Check Dash Configuration)

(Center air vents are above radio)

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: *These clips are tight, and will take some force to remove them. Also, the top strip above the bezel is a part of the bezel.* With a Wide Plastic Dash Tool, CAREFULLY! remove the radio/climate control bezel by starting at the right side by the corners pulling to release (1) clip at a time. Continue working your way around the bezel until all (7) clips are released. Set the bezel aside.

STEP #2 Place InDash by PanaVise Mount on to the right side edge of the dash cavity. Be sure the edge of the mount is flat against the side. Install the (3) screw provided into the dash. Press the mount to the right before tightening.

STEP #3: Replace the bezel carefully.



Mounting location can vary, as long as mount is flush to side and bottom edge of dash

INSTALLATION IS NOW COMPLETE.
ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



InDash installed showing a location



07-11-12