

INDASH by PANAVISE®

I-75137-905

Page 1 of 1

MOUNTING LOCATION:

Right side of climate control CR

TOOLS REQUIRED:

Hook tool

Phillips screwdriver

HARDWARE INCLUDED:

(3) A #8x9/16" Needle Pt Screw

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#:75137-905

MFG: TOYOTA

MODELS & YEARS: Tacoma 05-12

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With hook tool remove the climate control assembly. Begin by inserting the hook tool into a corner of the climate control plate. Pull to release a total of (4) clips. Set climate control down, and you do not need to disconnect any wires.

STEP #2: Place the InDash by PanaVise Mount along the right side of the climate control cavity with the joggle aligned up with the ledge of the dash. Install the (3) supplied screws making sure they go in straight and seat flat on the mount.

STEP #3: Replace the climate control bezel.

INSTALLATION IS NOW COMPLETE.

ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Prototype InDash showing placement



Prototype InDash installed showing location



02-29-12